

*** Required to upgrade to Ver 2 Balance Chamber

UF SUB RACK

Part Number	Name	Description	Qty.
BALANCE CHAMBER Version 2			
34562292	Balance Chamber Outer Part	Block *** X 2	1
34562291	Balance Chamber Middle Part	Block *** X 1	1
3451902C	Solenoid Valve 2/2 way [Connector/Flange]	VDEBK1/2, VDABK1/2, VABK1/2	1
34570901	O-Ring 5.6 X 1.6	For the Valves with V2 Block	3
34562293	Coil (Serial # > 267600)	V2 Coil with V2 Block *** X 2	1
34770852	O-Ring 11.1 X 1.6	For the V2 Coils with V2 Block *** X 1	1
3451906C	Solenoid Valve 2/2 way [Connector/Connector]	VDA-VEBK1/2	1
3451665A	Membrane Position Sensor Board	MSBK 1/2 Boards	1
3451615A	Membrane for Balance Chamber	Membranes [Replace as Pair]	1 pair
3451897B	Repair Kit Balance Chamber	For Complete Replacement of both Membranes Also Incl. o-rings & hardware *** X 1	1 kit
AIR SEPARATOR			
34560190	LID (AIR SEPARATOR)	Lid Only	1
34562215	HOUSING AIR SEPARATOR V1	Square Block without Lid SN# 230332 ↓	1
34562216	Air separator V2	Molded Block SN# 230333 ↑	1
3451902C	Solenoid Valve 2/2 way [Connector/Flange]	VLA-VBP	1
34561706	Pressure Controller 0.4 BAR	DDE	1
34562217	ADAPTER DDE	Holder for DDE Injection molded	1
34561722	Pressure Controller 1.3 BAR	RVFPA/RVFPE	1
34570683	O-ring 4.47 x 1.78	For RVFPE/RVFPA/DDE/RVDA	10
3451916A	Tubing Connector [8 x 1/8"]	Connectors on Air Separator	5
MISC.			
34561501	Filter 4.6MM	FBK1 / FBK2	5
3451614B	Temperature Sensor	TSDE [not including housing]	1
3477104A	O-Ring [8.3 x 2.4]	O-Ring for TSDE	1
34562060	Temperature Sensor inc. Wire	Temperature sensor with wires attached	1
34570730	Housing Complete for Temperature Sensor	Entire TSDE [including temp sensor]	1
34570195	TUBING CLAMP SNP - 1.5 [7.8 - 8.6 mm]	Black locking clamp	20
34570209	TUBING CLAMP SNP - 4 [10.3 -11.5 mm]	Black locking clamp	20
34570861	T-TUBING CONNECTOR 6-4-6 MM	(UFP,FPA,LA)	1
34570705	Y-TUBING CONNECTOR 8 MM	(VABK1,VABK2,RVDA) (VDEBK1,VDEBK2,LA) (VEBK1,VEBK2,FBK1)	1
3456222A	Wire Harness Valves and pumps		1